



Model Number
D564-XXX
S561-XXX

www.norix.com • TEL 800 234-4900

Assembly Notes: Norix is not responsible for any damage due to improper installation. If your shipment does not match the parts list, please contact Norix Customer Service at 800-234-4900. Norix reserves the right to modify design specifications at any time without an obligation to owners of previously sold products.

Parts List / Wall Mount				Tools Needed
ITEM	QTY.	PART NUMBER	DESCRIPTION	Low RPM Variable Speed Hammer Drill
A	4	025-007	Nut, 5/16-18, Hexagonal, Zinc	Concrete Drill Bit Size Matched to Anchors
B	4	025-011	Lock Washer, 5/16", Zinc	4 Concrete Anchors (not supplied 3/8" max)
C	1	040-060	Ironman Seat, 12", SST, 14Ga, 5/16-18 x 5/8	
D	1	060-211	Seat Arm, Ironman, Fixed, 15.5", Grey	
Parts List / Floor Mount				
ITEM	QTY.	PART NUMBER	DESCRIPTION	
A1	4	021-001	Machine Screw, 5/16-18 x 5/8	
B1	1	035-104	Stool, Bolt, 14Ga, 24", Grey	
C1	1	040-XXXX	Seat, 13", Super Slammer Stone	

Step 1:

Place the stool leg in the desired installation location. Mark the floor or wall through each of the four holes of the stool leg or mounting plate.

Step 2:

Drill and prepare the holes for anchoring with accordance with the suppliers instructions.

Step 3:

Fasten the seat to the plate on the stool leg that has the counter sunk holes. Secure by hand starting four (4) 5/8" Torx tamper-resistant screws finish with the tool provided. Steel seats are attached using 5/16" washers and nuts. (Provided) When attaching steel seats, tighten the nuts using a torque wrench. TIGHTEN TO A TORQUE VALUE OF 10 ft-lbs. (120 in-lbs.)

Fasten the stool leg to the floor in accordance with the suppliers instructions.

