



**FurrowForce Installation Manual**  
**Precision Planting®**

## Installing FurrowForce Assembly to the Row Unit

**Note:** This step is universal across all row units.

Remove the M10 cross bolt from the interface bracket (if installing on a Kinze row unit, the bolt is included in the hardware kit for the interface bracket).

Place the assembly on the respective interface bracket so that the ears on the FurrowForce assembly line up with the bushing mounts on the interface bracket as shown. Install the M10 cross bolt through the interface bracket and the FurrowForce assembly. Secure with the top-lock nut provided.

**Note:** Torque the nut until the interface bracket is tight with the FurrowForce assembly.

