



XD GUARDIAN D SERIES™




OPTIONAL MOUNTING KITS



ORIENTATION & SWIVEL






THROUGH-HOLE INSTALLATION

1 Place the riser in the through hole on the fixture.

XD GUARDIAN D SERIES™ PRODUCT MANUAL




2 From the underside, slide the circular mounting plate all the way over the post with the gap facing the front of the position.



SLOT INSTALLATION






DUAL-POST INSTALLATION




2 From the underside, slide the circular mounting plate all the way over the post with the gap facing the front of the position.



BRACKET INSTALLATION




- **1** Mate the product brackets by aligning the bars so that the bars with caterpillar holes are on the outside and slide the products together.
- **2** Seat the device brackets onto the XD Guardian D Series Base.




INSTALLATION




5 Route the product end of the power cable trough the opening on the front of the XD Guardian D Series position.



7 Slide the top half of the device bracket up, and place the product in the bracket. Slide the top half of the device bracket down to snugly fit around the product. Press the barrel lock to lock the brackets into place.



6 FOR TABLET BRACKETS ONLY: Align the holes on the tablet bracket bar to the holes on the riser. Use the two included screws to secure the bar into place.



8 Insert the key into the barrel lock and turn clockwise to unlock. Push on the cylinder in the middle of the lock to re-lock.

