











INSTRUCTIONS

(1) Key Operating Instructions

- POWER**
- ① Long press three seconds is power on/off
 - ② In Wireless mode when get the calling, Short Press is answer the calls, Long Press is Refuse to listen, continuous push 3 times is redial
 - ③ Playing: Short Press Play/Pause
- VOL-**
- ① In Wireless/MP3 mode, Short Press: Previous, Long Press: volume-
 - ② In FM mode, Short Press: Previous, Long Press: volume-
- VOL+**
- ① In Wireless/MP3 mode, Short Press: next, Long Press: volume+
 - ② In FM mode, Short Press: next frequency, Long Press: volume+
- (2) LED Indicator**
- ① Wireless mode pairing status blue light flashing, after pairing the blue light slow flashing
 - ② In MP3 mode, the blue light will slow flashing when playing
 - ③ In FM mode, when listening to the radio station blue light search radio flashing
 - ④ In charging mode, the red light will be on for a long time when charging, and the blue light will be displayed after charging
- (3) LINE Connecting TO Audio Jack**
- ① Insert audio line, Go directly to the AUX LINE IN pattern, at this time for ordinary headset/headphones, buttons
 - ② Support mobile phone/Pod/MP4/MP3/CD/PC, etc
- (4) Functional Parameter**
- | | |
|--------------------------------------|-------------------------------|
| ① USB charge: DC5VIN | ② SNR: 88db |
| ③ FM frequency: 87.5-108MHz | ④ Wireless distance: 10meters |
| ⑤ Frequency: 56K-20KHz | ⑥ Output power: 25mW |
| ⑦ Wireless Frequency: 2.401-2.480GHz | ⑧ Charging time: 2hours |
| ⑧ Call duration: 8hours | ⑨ Standby time: 18hours |













