



Zoblise soap dispensers Automatic Soap Dispenser Soap Dispense

\$23.99

Product Code: 7J-57T4-N7C2


Availability: In Stock

First Available: 2021-07-27

Brand: Zoblise

Qty

ADD TO CART



PRODUCT DESCRIPTION

Zoblise soap dispensers Automatic Soap Dispenser Soap Dispenser,Hands Free Foaming Soap Dispenser, 240ml Foaming Hand Soap Dispenser Countertop Soap Dispensers Touchless Soap Pump for Bathroom Kitchen

- **AUTOMATIC FOAMING SOAP DISPENSER:** Fully touchless foaming soap dispenser with high foam and low foam modes, it better meets your requirement. Add foam soap to the tank or regular hand soap mixed with 4 times, get foaming hand soap within 0.2 s
- **QUICK INSTALLATION & SAFETY REFILL:** Remove the soap tank from the bottom to refill. You don't have to worry about the damage by liquid seeping into the dispenser through the button.
- **HIGH PRECISE SENSOR DESIGN:** With quick sensor design, it could be activated in high speed and dispense foam instantly by a wave.
- **EASY OPERATION:** Operate it with a single button. Press it to turn on/off, long press for 3 seconds to choose high/low soap mode
- **CAPACITY:** 240ml/8.12OZ capacity with visible volume. Please use 1.5V AA batteries in our foaming hand soap dispenser! Or it won't work!!!

Product description

Rich foam

Get richer foam without foaming by hand

If you use regular hand soap mixed with water, we recommend to mix 1 cup of soap and 3-4 cups water.

The amount of soap could be switched to high mode(1.0g each time) and low mode (0.6g each time) by pressing power button for 3 seconds.

Touchless operation

You don't need to touch soap, or press soap pump, get rich foam by a wave easily.

Touchless soap dispenser is a great choice when your hands get dirty in kitchen, bathroom or hospital.

25° bevel design keeps outlet clean

The bevel design keeps a distance between soap foam and dispenser.

Dispenser could be clean and you don't need to clean it often.

DO & DO NOT:

DO dilute the hand soap with water in a ratio of 1:3 or 1:4 , then fill into the reservoir. Or it won't FOAM!

DO remove battery to avoid moisture and liquid leakage if not use it for a long time.

DO take out the hand soap and rinse for 10-20s to avoid blockage caused by the hand soap drying in the pipe.

DO NOT immerse the dispenser in water or rinse it, or it will short circuit.

DO NOT tilt the tank when installing or replacing hand sanitizer.

DO NOT use non-foam hand soap or it won't work.

DO NOT invert the dispenser.

DO NOT block the foam outlet with your hand.

PRODUCT INFORMATION

Is Discontinued By Manufacturer : No

Item model number : Z7845101

Manufacturer : Zoblise

OUR PRODUCTS

RELATED PRODUCTS

INFORMATION

[About Us](#)

[Refund policy](#)

[Privacy Policy](#)

[Terms & Conditions](#)

CUSTOMER SERVICE

[Returns](#)

[Site Map](#)

EXTRAS

[Brands](#)

[Gift Certificates](#)

[Affiliate](#)

[Specials](#)

[My Account](#)

[Returns](#)

MY ACCOUNT

[My Account](#)

[Order History](#)

[Wish List](#)

[Newsletter](#)

Copyright © 2020.All Right Reserved.

