EverON High Availability Configuration Guide for Cougar 3000 Series Clustered NAS

Customer Order Number: ONS-DOC-CCG-3000, Rev A1
Text Part Number: 690-0030-0001, A1

ONStor, Inc.
254 East Hacienda Ave.
Campbell, CA 95008
(408) 963-2400

Contents

Preface i
Audience ..... i-ii
Scope ..... i-iii
Related Documentation ..... i-iv
Revision Trail ..... i-v
Syntax Usage ..... i-vi

Chapter 1: Overview of ONStor Clustering 1-1
Introduction to ONStor Clustering 1-2
Understanding High Availability and Virtual Servers 1-2
Understanding Clusters and Failover 1-2
Understanding Clusters and Load Balancing 1-2
Understanding Clustering Configurations 1-2
The Primary Cluster Controller (PCC) 1-6
Primary Cluster Controller Election 1-6
Primary Cluster Controller in Runtime 1-6
The Cluster Database 1-8
Clusters and Time Sources 1-8

Chapter 2: Configuring Management Network Clusters 2-1
Configuring a Management Network Cluster 2-2
Creating a Management Network Cluster 2-2

Chapter 3: Configuring Hybrid Network Clusters 3-1
Configuring a Hybrid Network Cluster 3-2
Creating a Hybrid Network Cluster 3-2

Chapter 4: Configuring Direct-Connect Clusters 4-1
Configuring a Direct-Connect Cluster 4-2
Creating a Direct Connect Cluster 4-2

Chapter 5: Software Configuration 5-1
Connecting to the Node 5-2
Verify Node Firmware Installation 5-3
Configuring Name Resolution Through DNS 5-5

Configuration Tasks in the Management Virtual Server Context 5-6
Create Volumes on the Management Virtual Server 5-6
Create Interface and Route to the Management Virtual Server 5-8
Configuration Tasks for Virtual Servers 5-10
Create and Configure a Virtual Server for Data Storage 5-10
Add Virtual Server to Network Domain 5-11
Create Share Point for the Virtual Server 5-12
Configuration Tasks in the Management Virtual Server Domain Context 5-15
Create Volumes on the Management Virtual Server 5-15
Configuration of Additional Utilities 5-18
Event Monitoring and Report Service 5-18
AutoGrow 5-19
Snapshots 5-20

Chapter 6: Cluster Management Commands 6-1
Cluster Configuration Commands 6-2
Adding Nodes to a Cluster 6-2
Deleting Nodes from a Cluster 6-3
Committing Changes to a Cluster 6-3
Uncommitting Changes from the Cluster Database 6-3
Displaying the Cluster Configuration 6-4
Displaying Cluster Information 6-4
Adding a Node Group to a Cluster 6-5
Moving a Node Into or Out of a Group 6-6
Deleting a Node Group from a Cluster 6-6
Displaying a Node Group Configuration 6-7
Deleting a Cluster 6-7

Preface

This preface contains the front matter for the *EverON High Availability Configuration Guide for Cougar 3000 Series Clustered NAS* family of products. This preface contains the following sections:

- “Audience”
- “Scope”
- “Related Documentation”
- “Revision Trail”
- “Syntax Usage”