

Allsteel®
never sit still

SEATING


Sum



3. Seat Depth Adjustment — The depth of your seat adjusts to accommodate different leg lengths.
To change the seat depth, lift your weight off the seat. Pull and hold the lever as you push the seat forward or backward. Release the lever to lock seat in place.




1. Seat Height Adjustment — Enables the seat to adjust to the preferred height.
To raise the seat, lift your weight off the seat and pull up on the lever; release lever when seat reaches desired height.
To lower the seat, lift up on the lever while you are seated; release lever when seat reaches desired height.



4. Arm Height Adjustment — Enables the user to adjust the arm height based on body size, task, and personal preference.
Lift up on lever, and lift or lower arm height to desired position. Release lever to lock arm into place.



2. Tilt Lock — Locks and unlocks the chair from an upright position.
Slide tilt lever forward while the seat and back are upright for an upright work position.
Slide tilt lever back for continuous, fully supported reclining.



5. Arm Width and Depth Adjustment — Enables the user to adjust the arm width and depth based on body size, task, and personal preference.
Slide arm pad inward or outward to decrease or increase the width between arms.
Slide arm pad forward or backward to increase or decrease arm pad depth.



6. AutoFit Automatic Lumbar System — Automatically conforms to the user to offer customized back support in any seated position. No user adjustment is needed to position the lumbar – it adjusts automatically.

7. Avatar 2 Weight-Activated Control — Automatically uses your body weight to activate and balance the chair movement, creating a comfortable, supported position naturally. No user adjustment is needed to receive the optimal amount of recline tension - it adjusts automatically.