


Tango Technologies

Hip Protection Belt Quick Start Guide

Protection Only

Buckle the Belt


1. Place belt around waist, ensuring blue “UP” arrows are oriented upward.
2. Insert right buckle half into left at a slight angle.
3. Twist halves together to buckle and activate your belt. (Untwist the buckle halves to separate & unbuckle)



- ✓ The belt should rest comfortably on top of the pelvis with buckle centered on the torso.

Charging

- Plug charging cradle into wall outlet. Insert right belt buckle into charging cradle with belt lights facing up. (Similar motion to buckling belt)




- Belt lights will illuminate to indicate charge level.


Charging Status	
Low	● ○ ○
Medium	● ● ○
High	● ● ●
Full	● ● ● ●
Failing to charge	● ○ ○

Adjust the fit of the belt


1. While wearing the belt standing up, locate the sizing strap inside the left front zipper.



2. Pull up on the latch and adjust the length of the sizing strap to desired fit.



3. Once fit is achieved, firmly close latch squarely on strap to secure. Tuck excess strap smoothly into belt & close zipper.



✓ Belt should be comfortable, though not loose on the hips for proper fit.

Belt Feedback

- The belt provides feedback with vibration, chimes & lights.

LED indications

No lights	Belt is Off – Buckle belt to turn On
Green	Belt is functioning
Blinking green	Low Battery – Please charge
Blue	Wear error – Position belt correctly on user
Red	Fall detected or critically low battery

Contact support@ActiveProtective.com with any questions.